

Power Breezer Head Sleeve Instructions and Care



SCOPE

This guide provides users with written instructions for the installation and care of Power Breezer Head Sleeves.

REVISION HISTORY

Rev. No.	Date	Author	Comment
1	8-31-2021	Lance Sperring	Original Document

This Information is Proprietary:

No part of this document shall be reproduced, stored in a retrieval system, or transmitted by any means, electronic, mechanical, photocopying, recording, or otherwise, without written permission from the publisher. Although every precaution has been taken in the preparation of this Repair Guide, the publisher and author assume no responsibility for errors or omissions, nor is any liability assumed for damages resulting from the use of the information contained herein. The information contained herein is subject to change without notice.

Warnings:

- **Remove Head Sleeve PRIOR to storing head unit in tank** to avoid damaging Head Sleeve.
- Install and or remove Head Sleeve only when the Unit's Head is not oscillating or the Unit is powered off.

Care and Cleaning:

Your flexible Head Sleeve is made of 94% polyester and 6% spandex. It has been specially produced using washable and weatherproof materials and UV-based inks.

Care:

- To maintain the life of your Head Sleeve, we recommend you store it in a clean dust proof container after each use.
- Reclose the Velcro closure before storing to minimize pulls or snags to the Head Sleeve's fabric and or stitching.

Cleaning:

- Cold wash
- No bleach
- Light detergent
- Delicates
- Cool, tumble dry

Materials Required:

- Head Sleeve designed to fit your Mobile Unit model
- Mobile Unit

Installing the Headsleeve

- A. Unfold Head Sleeve and open Velcro closure.



- B. With the Velcro closure at the bottom and facing the back of the head, slide Head Sleeve over the front of the Unit's Head while working the fabric evenly on.



- C. Position the Head Sleeve over the Head only as far as the rear of the Head.



- D. After ensuring the sewn opening of the Head Sleeve is aligned with the Head Support Pole, fasten the Velcro closure.



If you have questions and or problems applying the procedures found in this guide, please contact Customer Service by email at customerservice@powerbreezer.com or by phone at 844-233-5673.